

















*
E2G V.....
INDICARE IL VOLTAGGIO
INDIQUER LA TENSION
PLS GIVE VOLTAGE
DIE SPANNUNG MITTEILEN


Hz.....
INDICARE LA FREQUENZA
INDIQUER LA FREQUENCE
PLS GIVE FREQUENCY
DIE FREQUENZ MITTEILEN

COMPONENTI ELETTROVALVOLE
COMPONENTS OF SOLENOID VALVES

COMPOSANTS DES ELECTROVANNES
BESTANDTEILE DER MAGNETVENTILE

TAB N° AV-1





IMPIANTO RISCALDAMENTO A GAS **M 30 BISTRO'** **laCIMBALI**

